



# HR-11 Heatsink

## Exploded View




## Component



Parts Name	Piece(s)
❶ HR-11 Heatsink	1
❷ M2x9 Screw	4
❸ M2.5x13 Screw	4

## Installation

Important! Before proceeding with installation, please check for the most up-to-date instructions at [www.thermalright.com](http://www.thermalright.com)



### Step 1:

Remove sheet from thermal pad.

### Step 2:

Select the appropriate screws in accordance to VGA's requirement.

### Step 3:

Insert the screws through the HR-11 base and the VGA card to secure in place.

### Step 4:

For SLI, HR-11 can also be installed, with it turned 90 degrees.

